

Congratulations on your purchase of the Beeping Easter Egg, which was designed to help Blind and Visually Impaired kids join in on the fun of Easter Egg Hunts. Instead of using visual cues, kids locate these eggs by following the beep they emit. They can also be used on Easter morning to give kids the added excitement of locating their Easter baskets. We hope these Beeping Easter Eggs become part of your Easter traditions for years to come!

DIRECTIONS FOR USE:

- Your Beeping Easter Egg comes with 2 Size “N” batteries already installed. To use, place the egg in the desired location and turn the beeper on using the ON/OFF switch.
- Once the egg has been found, the switch should be moved back to the OFF position.

(IMPORTANT: Holes in the eggs to allow the beeping sound to be heard more clearly. To avoid damaging the beeper, be careful not to expose the eggs to water.)

90-Day Warranty not including batteries or misuse (water damage, dropping, etc.)

To order additional eggs or replacement batteries, or if you have any questions, please contact us at: Phone: 1-800-522-6294 or email: sales@MaxiAids.com

Maxi-Aids, Inc.
42 Executive Blvd.
Farmingdale, NY 11735
Phone: 1-631-752-0521
Toll Free: 1-800-522-6294

Congratulations on your purchase of the Beeping Easter Egg, which was designed to help Blind and Visually Impaired kids join in on the fun of Easter Egg Hunts. Instead of using visual cues, kids locate these eggs by following the beep they emit. They can also be used on Easter morning to give kids the added excitement of locating their Easter baskets. We hope these Beeping Easter Eggs become part of your Easter traditions for years to come!

DIRECTIONS FOR USE:

- Your Beeping Easter Egg comes with 2 Size “N” batteries already installed. To use, place the egg in the desired location and turn the beeper on using the ON/OFF switch.
- Once the egg has been found, the switch should be moved back to the OFF position.

(IMPORTANT: Holes in the eggs to allow the beeping sound to be heard more clearly. To avoid damaging the beeper, be careful not to expose the eggs to water.)

90-Day Warranty not including batteries or misuse (water damage, dropping, etc.)

To order additional eggs or replacement batteries, or if you have any questions, please contact us at: Phone: 1-800-522-6294 or email: sales@MaxiAids.com

Maxi-Aids, Inc.
42 Executive Blvd.
Farmingdale, NY 11735
Phone: 1-631-752-0521
Toll Free: 1-800-522-6294